

AAF7630

Air Fryer

EASY START GUIDE

PACKAGE CONTENTS

- AAF7630 Air Fryer
- Removable Non-Stick Basket
- Removable Non-Stick Pan
- Easy Start Guide
- User Manual
- Warranty Policy

BEFORE USE

Before first use, make sure that the Air Fryer is unplugged. Clean the fry basket or fry pan and thoroughly dry. Place it in the fry drawer. Plug the cord into the outlet and you are now ready to use it. Do not expose the Air Fryer's heating base to water or any kind of liquid substance to avoid electric shock.

USING THE AIR FRYER

TIPS IN USING YOUR AIR FRYER

- Before use, please check if the power voltage of your Air Fryer correctly corresponds to your home's power supply.
- Ensure to position your appliance on a smooth, dry, and stable ground.
- Do not position the appliance in a humid environment and/or in places exposed to multiple sources of heat such as stoves. It is also important to keep it away from flammable/combustible materials especially during use.
- Close the cover correctly. or the capability of cooking and keeping warm may be affected due too poor sealing.
- If the Air Fryer falls onto the ground or is impacted by powerful external force accidentally, please send it for inspection because there is a risk of faults.

STEP 1: Plug to Outlet

Plug its power adapter to a power outlet. Make sure the power voltage of your Air Fryer correctly corresponds to your home's power supply.

STEP 2: Fill the Basket

Pull the fry drawer out from the product. Place the food inside the fry basket and push back the drawer into the product. Click the **ON/OFF** button. **Note:** Do not exceed the maximum line.

STEP 3: Select Function

Click on the function button that you need for your food. There are seven preset functions to choose from: Fry, Roast, Shrimp, Bake, Chicken, Steak, and Fish.

STEP 4: Adjust Time and Temperature

After choosing a function, you have the option to adjust the time and temperature or use the default. If you want to adjust the Time, just press the Time and Temperature Increase/Decrease buttons until you reach your desired unit. Then, you need to click the ON/OFF button once again for the air fryer to start cooking.

STEP 5: Serve Food

Once the appliance is finished, you will hear 5 beeps, and your food is ready to serve. Pull the drawer out and use a heat resisting material to move your food into a container. Disconnect the power plug after using the air fryer.