

**Aztech**

# MF801C

Aztech Multifunction Cooker

## USER MANUAL



PLEASE RETAIN THIS USER MANUAL FOR FUTURE USE.




# SAFETY INSTRUCTIONS

- Only use the intended cooking pot included in the product package.
- Position the Multifunction Cooker on a smooth, dry, and stable ground. Placing the appliance on unstable surfaces such as softly cushioned carpets or sofa, may make the appliance lose its balance.
- Do not position the appliance in hot places or in places commonly exposed to multiple sources of heat such as stoves, refrigerators, or ovens. It is also important to keep it away from flammable materials such as curtains and cloths.
- Remove the power plug before doing any cleaning or relocation of the appliance.
- Do not use wet hands in operating the appliance, and in inserting or removing its power plug to prevent electrical shocks. It is suggested to thoroughly dry your hands first before using the Multifunction Cooker.
- During use, keep the Multifunction Cooker and its wiring away from children to avoid injuries
- Should damages be found in the appliance, please do not use the appliance and immediately bring the appliance to the maintenance center for repair.
- When unplugging the power plug, do not pull its cord. Hold the power plug properly on its base to unplug it from the power outlet.
- Before using, check if the power voltage of your Multifunction Cooker corresponds to your home's power supply.
- If the power cord is damaged, do not replace it by yourself. Always use the dedicated power cord supplied by the manufacturer.
- After cooking, allow the cooking pot to cool down before removing the cooking pot for cleaning.
- Do not immerse the power cord and Multifunction Cooker's body into water to avoid breakage which may affect safety usage.
- Avoid any external or heavy impact on the glass lid.
- Do not use hard objects in cleaning the cooking pot. These materials may scratch the nonstick surface of the cooking pot, rendering it useless over time.


# PACKAGE CONTENTS

- Multifunction Cooker
- Fry Basket
- Steam Rack
- Power Supply
- User Manual
- Easy Start Guide
- Warranty Policy

# APPLIANCE OVERVIEW



# CONTROL PANEL BUTTONS



## 1. START/STOP Button

- After connecting and plugging the power supply, a BEEPING SOUND would be heard. Adjust the Time and Temperature using the +/- buttons as preferred then press this button to confirm and start cooking.

- After plugging the Multifunction Cooker to a power outlet, press the START/STOP button and it will return to its last setting. Press the FUNCTION button and it would renew the last function menu. Double press this button to stop the cooking and return the Multifunction Cooker to STANDBY mode.
- **Short Time Memory Function.** If the product has finished cooking, and you want to use the same preset again, press the START/STOP button again to use the previously used preset. Do take note that if you have unplugged the device or if you did not press this button within one minute after cooking, you would not be able to use the previous preset used.

## 2. TIME & TEMPERATURE (+/-) Button

- After choosing the preferred function, adjust the TIME using the **TIME + or TIME –** button. For each press, the cooking time shall increase or decrease by 1 minute. If you press and hold the TIME + or TIME - button, the time shall increase or decrease by 10 minutes. The maximum cooking time you can set is up to 9 hours and 59 minutes.
- Press the **TEMP + or TEMP –** button to adjust the temperature used in cooking. For each press, the temperature is increased or decreased by 10 degrees. If you press and hold the TEMP + or TEMP – button, the temperature shall increase or decrease by 10 degrees. The highest temperature you can set is up to 240 and the lowest temperature can be set up to 40.

## 3. PRESET Button

- **Allows you to select or use your preferred cooking preset.** After selecting the preferred cooking function, including the cooking time and temperature, press the PRESET button. The display screen would show the preset time and the PRESET button would start blinking to indicate that you have now entered Preset mode.
- In Preset mode, adjust the TIME and TEMPERATURE preset using each respective (+/-) buttons. Press the START/STOP button and the Multifunction Cooker would start cooking using the entered preset. If the preferred preset time or temperature has not been completed within 10 seconds, the Multifunction Cooker would return to the Preset Status and you would have to press the Preset button again if you want to adjust the Time and Temperature.

## 4. FUNCTION Button

The Multifunction Cooker is capable of providing you 18 Functions you would surely enjoy using.

- Simply press the FUNCTION button and you would now be able to select the preferred function in a circular motion using the corresponding order : (1) Fry, (2) Cake, (3) Snacks, (4) Defrost, (5) Chocolate, (6) Keep Warm, (7) Pizza, (8) Soup, (9) Toast, (10) Vegetable, (11) Yoghurt, (12) Deep Fry, (13) Porridge, (14) Stir Fry, (15) Hot Pot, (16) Steam, (17) Meat, and (18) Grill.

- Press the **START/STOP** button and the Multifunction Cooker will begin cooking using the selected function. If you wish to change the cooking function, you would have to cancel the cooking first by pressing the **START / STOP** button and the Multifunction Cooker would return to **STANDBY** mode.

## USING THE COOKING FUNCTIONS

### A. FRY

1. Press the **FUNCTION** button to select the **FRY** function. The **FRY** function indicator would start blinking.
2. Pour cooking oil and place the food on the cooking pot.
3. Press the **START/STOP** button and set the preferred cooking time and temperature. The default temperature is set to 200°C, while the Time is set to 20 minutes. You can set the preferred frying time from 1 minute to 10 hours, while the Temperature can be set from 120°C to 240°C.
4. The Multifunction Cooker will automatically return to **STANDBY** mode after cooking.

### B. CAKE

1. Press the **FUNCTION** button to select the **CAKE** function. The **CAKE** function indicator would start blinking.
2. Press the **START/STOP** button and set the preferred cooking time. The default temperature is set to 140°C, while the Time is set to 1 Hour. You can set the preferred cooking time from 1 minute to 1.5 hours, but the temperature cannot be adjusted.
3. Spray or paint oil around the pot, and keep preheating for 1 minute. You may then pour the cake mixture into the pot and place the glass lid. The Multifunction Cooker will automatically return to **STANDBY** mode after cooking.

### C. SNACKS

1. Place the snacks that you wish to cook into the cooking pot then place the glass lid.
2. Press the **FUNCTION** button to select the **SNACKS** function. The **SNACKS** function indicator would start blinking.
3. Press the **START/STOP** button and set the preferred cooking time. The default temperature is set to 160°C, while the Time is set to 30 minutes.
4. You can set the preferred baking time from 1 minute to 30 minutes, but the temperature cannot be adjusted. The Multifunction Cooker will automatically return to **STANDBY** mode after cooking.

## D. DEFROST

1. Place the Steam Rack or Low Rack over the non-stick cooking pot.
2. Place the frozen food on the rack and the glass lid to close it.
3. Press the **FUNCTION** button to select the **DEFROST** function. The **DEFROST** function indicator would start blinking.
4. Press the **START/STOP** button and set the preferred cooking time. The default temperature is set to 80°C, while the Time is set to 1 hour.
5. You can set the preferred defrosting time from 30 minutes to 3 hours, but the temperature cannot be adjusted. The Multifunction Cooker will automatically return back to STANDBY mode after cooking.

## E. CHOCOLATE

1. Pour the chocolate mixture on the cooking pot and close using the lid.
2. Press the **FUNCTION** button to select the **CHOCOLATE** function. The **CHOCOLATE** function indicator would start blinking.
3. Press the **START/STOP** button and set the preferred cooking time. The default temperature is set to 60°C, while the Time is set to 2 hours.
4. You can set the preferred cooking time from 30 minutes to 4 hours, and the temperature can be set from 60°C to 70°C. The Multifunction Cooker will automatically return back to STANDBY mode after cooking.

## F. KEEP WARM

1. Press the **FUNCTION** button to select the **KEEP WARM** function. The **KEEP WARM** function indicator would start blinking.
2. Press the **START/STOP** button and set the preferred cooking time. The default temperature is set to 80°C, while the Time is set to 2 hours.
3. You can set the preferred cooking time from 30 minutes to 4 hours, but the temperature cannot be adjusted. The Multifunction Cooker will automatically return back to STANDBY mode after cooking.

## G. PIZZA

1. Place the Low Rack on the non-stick cooking pot, then place the pizza on the rack and close it with the glass lid.
2. Press the **FUNCTION** button to select the **PIZZA** function. The **PIZZA** function indicator would start blinking.
3. Press the **START/STOP** button and set the preferred cooking time. The default temperature is set to 160°C, while the Time is set to 40 minutes.
4. You can set the preferred cooking time from 1 minute to 1 hour, but the temperature cannot be adjusted. The Multifunction Cooker will automatically return back to STANDBY mode after cooking.

## H. SOUP

1. Place the raw mixture into the cooking pot, add the needed water and close it with the glass lid.
2. Press the **FUNCTION** button to select the **SOUP** function. The **SOUP** function indicator would start blinking.
3. Press the **START/STOP** button and set the preferred cooking time. The default temperature is set to 100°C, while the Time is set to 3 hours.
4. You can set the preferred cooking time from 30 minutes to 4 hours, but the temperature cannot be adjusted. The Multifunction Cooker will automatically return back to STANDBY mode after cooking.

## I. TOAST

1. Place the low rack on the cooking pot and close it with the glass lid.
2. Press the **FUNCTION** button to select the **TOAST** function. The **TOAST** function indicator would start blinking.
3. Press the **START/STOP** button and set the preferred cooking time. The default temperature is set to 160°C, while the Time is set to 20 minutes.
4. You can set the preferred cooking time from 1 minute to 30 minutes, but the temperature cannot be adjusted.
5. **Flip the bread every 10 minutes.** The Multifunction Cooker will automatically return back to STANDBY mode after cooking.

## J. VEGETABLES

1. Pour some water in the cooking pot, then place the vegetables and the glass lid to close.
2. Press the **FUNCTION** button to select the **VEGETABLE** function. The **VEGETABLE** function indicator would start blinking.
3. Press the **START/STOP** button and set the preferred cooking time. The default temperature is set to 140°C, while Time is set to 25 minutes.
4. You can set the preferred cooking time from 10 minutes to 1 hour, and the temperature can be set from 120°C to 180°C. The Multifunction Cooker will automatically return to KEEP WARM mode after cooking.

## K. YOGHURT

1. Pour fresh milk into the cooking pot, add yoghurt cultures or 10% pure yoghurt then place the glass lid.
2. Press the **FUNCTION** button to select the **YOGHURT** function. The **YOGHURT** function indicator would start blinking.
3. Press the **START/STOP** button and set the preferred cooking time. The default temperature is set to 40°C, while the Time is set to 4 hours.
4. You can set the preferred cooking time from 30 minutes to 10 hours, but the temperature cannot be adjusted. The Multifunction Cooker will automatically return to STANDBY mode after cooking.



## L. DEEP FRY

1. Place the raw food you would be cooking and pour the needed cooking oil into the cooking pot enough to submerge the fry basket and the food you would be frying.
2. Press the **FUNCTION** button to select the **DEEP FRY** function. The **DEEP FRY** function indicator would start blinking.
3. Press the **START/STOP** button and set the preferred cooking time. The default temperature is set to 210°C, while the Time is set to 40 minutes.
4. You can set the preferred cooking time from 1 minute to 2 hours, while the temperature can be set from 180°C to 210°C. The Multifunction Cooker will automatically return to STANDBY mode after cooking.

## M. STIR FRY

1. Press the **FUNCTION** button to select the **STIR FRY** function. The **STIR FRY** function indicator would start blinking.
2. Press the **START/STOP** button and set the preferred cooking time.
3. Pour a moderate amount of cooking oil in the pot. The default temperature is set to 240°C, while the Time is set to 15 minutes.
4. You can set the preferred cooking time from 1 minute to 30 minutes, while the temperature can be set from 140°C to 240°C. The Multifunction Cooker will automatically return back to STANDBY mode after cooking.

## N. PORRIDGE

1. Put clean rice into the cooking pot, add burdening and water then place the glass lid.
2. Press the **FUNCTION** button to select the **PORRIDGE** function. The **PORRIDGE** function indicator would start blinking.
3. Press the **START/STOP** button and set the preferred cooking time. The default temperature is set to 110°C, while Time is set to 1 hour.
4. You can set the preferred cooking time from 1 minute to 1.5 hours, while the temperature can be set to 100°C to 140°C. The Multifunction Cooker will automatically return back to STANDBY mode after cooking.

## O. HOT POT

1. Press the **FUNCTION** button to select the **HOT POT** function. The **HOT POT** function indicator would start blinking.
2. Press the **START/STOP** button and set the preferred cooking time. The default temperature is set to 220°C, while the Time is set to 1 hour.
3. You can set the preferred cooking time from 1 minute to 10 hours, while the temperature can be set from 120°C to 240°C. The Multifunction Cooker will automatically return back to STANDBY mode after cooking.

## P. STEAM

1. Place the Steam Rack or Low Rack over the cooking pot.
2. Add the right amount of water enough to keep the water below the rack then place the raw food you plan to steam and close using the glass lid.
3. Press the **FUNCTION** button to select the **STEAM** function. The **STEAM** function indicator would start blinking.
4. Press the **START/STOP** button and set the preferred cooking time. The default temperature is set to 220°C, while the Time is set to 15 minutes.
5. You can set the preferred cooking time from 1 minute to 30 minutes, while the temperature can be set from 120°C to 240°C. The Multifunction Cooker will automatically return back to STANDBY mode after cooking.

## Q. MEAT

1. Place the meat into the cooking pot then add the right amount of water and close using the glass lid.
2. Press the **FUNCTION** button to select the **MEAT** function. The **MEAT** function indicator would start blinking.
3. Press the **START/STOP** button and set the preferred cooking time. The default temperature is set to 160°C, while the Time is set to 30 minutes.
4. You can set the preferred cooking time from 1 minute to 10 hours, while the temperature can be set from 120°C to 180°C. The Multifunction Cooker will automatically return back to keep warm mode after cooking.

## R. GRILL

1. Place the steam rack or the low rack on the cooking pot and place the glass lid.
2. Place the marinated chicken or meat into the rack and close the lid.
3. Press the **FUNCTION** button to select the **GRILL** function. The **GRILL** function indicator would start blinking.
4. Press the **START/STOP** button and set the preferred cooking time. The default temperature is set to 240°C, while Time is set to 30 minutes.
5. You can set the preferred cooking time from 1 minute to 30 minutes, while the temperature can be set to 120°C to 240°C. The Multifunction Cooker will automatically return back to STANDBY mode after cooking.

## CARE AND CLEANING

1. The glass lid is frangible. Avoid exposing it to heavy external impacts or force and continually handle it with care.
2. If the nonstick cooking pot has materials stuck on its surface, use vinegar together with boiling water to remove the attached particles.
3. When washing, ALWAYS use a soft sponge. Do not use steel wire balls or any hard and abrasive materials in cleaning the cooking pot.
4. Do not use any corrosive liquids in cleaning the body, the cooking pot, or any part of the Multifunction Cooker.
5. If you do not have to use the product for a long time, please completely clean and place the Multifunction Cooker into its box and store it in a dry and well-ventilated area.
6. If the product is found faulty, please contact your local dealer at once. Do not, in any kind of manner, disassemble, dismantle, or repair the product by your own. This may void the appliance's warranty.

# Aztech