

Aztech

AAF7630

Air Fryer

USER MANUAL



PLEASE KEEP THIS USER MANUAL FOR FUTURE USE.

USER MANUAL CONTENTS

SAFETY INSTRUCTIONS.....	2
PACKAGE CONTENTS.....	4
APPLIANCE OVERVIEW.....	4
BEFORE USE.....	5
USING THE AIR FRYER.....	5
HELPFUL HINTS.....	5
CLEANING AND MAINTENANCE.....	6
RECIPES.....	7

SAFETY INSTRUCTIONS

NOTE: It is STRONGLY ADVISED to ensure that you have read all provided safety guides and operating instructions in this user manual first before proceeding.

- Do not immerse or expose your Air Fryer's main body and/or its power cord to water or any kind of liquid substance to avoid electric shock. In addition, do not use abrasive products (e.g. steel wool pads) whenever cleaning since these may damage the appliance's surface.
- Ensure all packaging materials and any promotional labels or stickers are removed from the appliance before the first use.
- Do not touch the inside of the product, or there could be a risk of scald.
- Your Aztech Air Fryer is not intended for people with reduced physical, sensory or mental capabilities, and/or lack of experience or knowledge. Constant supervision (from a person responsible for their safety) should be provided if such individuals would be using, cleaning, or operating, the appliance.
- Keep the appliance out of reach of children. If children are within the area during use, ensure to operate the appliance with extra care for safety purposes. Keep its power cord safely kept away and out of reach during use to avoid unwanted accidents.
- Should damages be found on the appliance, its power cord and/or its other components – do not use the appliance and immediately bring it to the Aztech Service Center for repair or replacement.
- Do not, in any kind of manner, disassemble, dismantle, and/or perform appliance repair on your own and/or replace its components using non-Aztech approved components and/or attachments.


- Do not position the appliance in a humid environment and/or in places exposed to multiple sources of heat such as stoves, refrigerators, or microwave ovens. It is also important to keep it away from flammable/combustible materials such as electric burners, curtains and/or cloths especially during use.
- When unplugging its power adapter, do not pull or tug its cord. Hold the power adapter firmly on its base when unplugging it from the power outlet. Also, ensure that its power cord is kept away from any source of heat and/or sharp edges that may cause external damage to the cord.
- Considering the high-temperature air exhausted from the air outlet, please do not allow your face or hands to get close to the air outlet or cover in the cooking process, or there could be a risk of scald.
- Do not use the appliance and/or its components for anything other than its intended purpose. The appliance is intended for household use only, commercial usage would void the warranty of the appliance.
- Before use, please check if the power voltage of your Air Fryer correctly corresponds to your home's power supply.
- Ensure to ALWAYS position your Air Fryer on a smooth, dry, and stable ground. Placing the appliance on unstable surfaces such as cushioned carpets and/or uneven surfaces may cause the appliance to lose its balance during operation.
- Do not use wet hands in inserting or removing its power adapter to prevent electrical shocks. It is recommended to thoroughly dry your hands first before every use.
- Do not pull the drawer out during the process of using the product. If needed, set the timer to '0' first before pulling the drawer.
- Do not switch on/off or disconnect the power plug during the cooking process.
- Place the Air Fryer 30 cm away from the wall or furniture to avoid damage to the wall or furniture.
- Do not share the power socket with any other electrical appliance because it is likely to cause overheating to the power socket, electrical sparks to the cable or other unexpected accidents.

PACKAGE CONTENTS

- AAF7630 Air Fryer
- Removable Non-Stick Basket
- Removable Non-Stick Pan
- Easy Start Guide
- User Manual
- Warranty Policy

APPLIANCE OVERVIEW

AIR FRYER COMPONENTS



- | | | |
|------------------|---------------------------------|---------------------------------|
| 1. Air Inlet | 6. Fry Drawer | 11. Temperature Decrease Button |
| 2. Control Panel | 7. Protective Cover | 12. ON/OFF Button |
| 3. Air Outlet | 8. Push-release Button | 13. Mode Selection Button |
| 4. Power Plug | 9. Handle Bar | 14. Time Increase Button |
| 5. Fry Basket | 10. Temperature Increase Button | 15. Time Decrease Button |

BEFORE USE

Before first use, make sure that the Air Fryer is unplugged. Clean the fry basket or fry pan and thoroughly dry. Place it in the fry drawer. Plug the cord into the outlet and you are now ready to use it. Do not expose the Air Fryer's heating base to water or any kind of liquid substance to avoid electric shock.

USING THE AIR FRYER

TIPS IN USING YOUR AIR FRYER

- Before use, please check if the power voltage of your Air Fryer correctly corresponds to your home's power supply.
- Ensure to position your appliance on a smooth, dry, and stable ground.
- Do not position the appliance in a humid environment and/or in places exposed to multiple sources of heat such as stoves. It is also important to keep it away from flammable/combustible materials especially during use.
- Close the cover correctly, or the capability of cooking and keeping warm may be affected due too poor sealing.
- If the Air Fryer falls onto the ground or is impacted by powerful external force accidentally, please send it for inspection because there is a risk of faults.

STEP 1: Plug to Outlet

Plug its power adapter to a power outlet. Make sure the power voltage of your Air Fryer correctly corresponds to your home's power supply.

STEP 2: Fill the Basket

Pull the fry drawer out from the product. Place the food inside the fry basket and push back the drawer into the product. Click the **ON/OFF** button.

Note: Do not exceed the maximum line.

STEP 3: Select Function

Click on the function button that you need for your food. There are seven preset functions to choose from: Fry, Roast, Shrimp, Bake, Chicken, Steak, and Fish.

STEP 4: Adjust Time and Temperature

After choosing a function, you have the option to adjust the time and temperature or use the default. If you want to adjust the Time, just press the Time and Temperature Increase/Decrease buttons until you reach your desired unit.

Then, you need to click the **ON/OFF** button once again for the air fryer to start cooking.

STEP 5: Serve Food

Once the cooking is finished, you will hear 5 beeps, and your food is ready to serve. Pull the drawer out and use a heat resisting material to move your food into a container. Disconnect the power plug after using the air fryer.

CLEANING AND MAINTENANCE

NOTE: Do not immerse your Air Fryer's main body and/or its power cord, in water and/or in any kind of liquid substance.

CLEANING THE AIR FRYER

1. Unplug the power adapter and allow the appliance to cool down.
2. Using a damp cloth, wipe off its external surface to remove dirt and/or other particles. Please do not use abrasive products in cleaning these areas since these may damage the appliance's surface.
3. Removable fryer and other accessories can be washed, as normal kitchenware.
4. Make sure all parts and accessories are dry thoroughly prior to plugging air fryer in and using.



WARNING!

- For safety's sake, when using a non-stick cookware or electric appliance with non-stick coatings, keep your pet birds out of the room. Birds have respiratory systems that are sensitive to many kinds of fumes, including from overheated non-stick.
- Do not exceed the maximum level line.
- Do not fill oil in the basket or drawer, otherwise it may cause fire.

RECIPES

GOLDEN CHICKEN WINGS

- 500g Chicken wings
- 2 pcs Garlic
- 2 teaspoon Ginger powder
- 1 teaspoon Cumin powder
- 1 teaspoon Black pepper powder
- 100 mg Sweet chili sauce

- Set temperature to 200 degrees and timer to 5 minutes for preheating the air fryer;
- Stir Garlic, ginger powder, cumin powder, spicy black pepper and a litter salt together, and then coated in the chicken wings;
- Chicken wings placed 20 minutes;
- Put chicken wings into fried basket evenly, set time for 15-20 minutes or until become golden brown.

ASIA SPICY FRIES

- 4 pcs/ 600g Potato
- 2 teaspoons Oil
- 1 teaspoon Salt
- 1 teaspoon Pepper powder
- 1 teaspoon Scallions powder
- 1/2 teaspoon Red chili powder

- Peel potatoes and cut into strips;
- Dipping potato strips into salt water at least 20mins, and then make dry with kitchen paper;
- Well mix shallot, salt and pepper, garlic powder/ garlic oil, red chili powder; Stir in potato strips;
- Set temperature to 180 degrees and timer to 5 minutes for preheating the air fryer;
- Place potato strips into the frying basket, put frying basket back to Air Fryer, and set the timer for 15-20minutes (depending on the amount of fries), or until the fries become golden brown.

Tip: turn over the fires by shaking the basket in the middle of cooking process, for better cooking result.

FRIED CORN

- 2 pcs Corn
- 2 teaspoon Olive oil

- Set temperature to 200 degrees and timer to 5 minutes for preheating the air fryer;
- Apply a thin layer of olive oil to the corn, slip fried baskets into the air fryer and the timer set for 10 minutes or baked until Golden

Aztech