

AIF4630

Infrared Cooker

EASY START GUIDE

PACKAGE CONTENTS

- AIF4630 Infrared Cooker
- User Manual
- Easy Start Guide
- Warranty Policy

BEFORE USE

Before first use, make sure that the appliance is unplugged and is in the “OFF” state. Clean all accessories from the package, thoroughly dry them, and re-assemble into the appliance. Plug the cord into the outlet and you are now ready to use it. This will ensure that all residues left from the manufacturing process are completely removed before using it.

USING THE INFRARED COOKER

TIPS IN USING YOUR INFRARED COOKER

- Before use, please check if the power voltage of your Induction Cooker correctly corresponds to your home's power supply.
- Do not position the appliance in a humid environment and/or in places exposed to multiple sources of heat such as stoves, refrigerators, or microwave ovens and/or near objects which will be affected by magnet such as radios, televisions, automatic-banking cards and cassette tapes.
- Do not cook without load or overload of food. Otherwise, it will cause deformation of the pot and the appliance.
- Do not power on the appliance with an empty pot as this will cause damage and deformation to the pot.

STEP 1: Plug to Outlet

Plug its power adapter to a power outlet. Make sure the power voltage of your Infrared Cooker correctly corresponds to your home's power supply.

STEP 2: Fill the Pot

Place the food inside the pot and place it on the heater plate of the product.

Note: Do not cook without load or overload of food. Otherwise, it will cause deformation of the pot and the appliance.

STEP 3: Turn On the Cooker

Press the ON/OFF key to start your cooking.

Note: When plugged into the socket and turned on, the fan will start and all indicators will flash for one time and the display is ----. The power indicator is flashing and you will hear a “bee” sound. The fan will stop if there will be no operation within 1 minute.

STEP 4: Adjust Firepower

Press any + or - key to adjust the firepower into large or small and the hot indicator lamp will light up.

STEP 5: Adjust Timer



Determine the cooking time. Set the timer to the desired cooking time by pressing the TIMER key.

STEP 6: Serve Food

After cooking has finished, timer will automatically turn the appliance off or you can manually power off the appliance. Unplug after using.

COOKWARE CHOICES

Any pot could be used such as iron, aluminum, copper, ceramics, marmite heat-resistant glass and any heat-resistant utensils. The infrared cooker makes use of the far infrared to heat the food so it is recommended to choose the best cookware to make it more effective. We suggest choosing flat-bottomed pan as below:



CLEANING THE INFRARED COOKER

- Unplug the power adapter and allow the appliance to cool down.
- Using a damp cloth, wipe off its external surface to remove dirt and/or other particles. Please do not use abrasive products in cleaning these areas since these may damage the appliance's surface.
- Make sure all parts and accessories are dry thoroughly prior to plugging in and using.